


Redundant Contact Input (CINR) Block

PSS 41S-3CINR

Product Specification

March 2019



Legal Information

Schneider Electric, EcoStruxure, Foxboro, I/A Series, and Triconex are trademarks and the property of Schneider Electric SE, its subsidiaries and affiliated companies. All other trademarks are the property of their respective owners.

This guide and its content are protected under applicable copyright laws and furnished for informational use only. No part of this guide may be reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), for any purpose, without the prior written permission of Schneider Electric.

Schneider Electric does not grant any right or license for commercial use of the guide or its content, except for a nonexclusive and personal license to consult it on an "as is" basis.

Schneider Electric products and equipment should be installed, operated, serviced, and maintained only by qualified personnel.

As standards, specifications, and designs change from time to time, information contained in this guide may be subject to change without notice.

To the extent permitted by applicable law, no responsibility or liability is assumed by Schneider Electric and its subsidiaries for any errors or omissions in the informational content of this material or consequences arising out of or resulting from the use of the information contained herein.

Overview


The Redundant Contact Input (CINR) block scans redundant contact inputs from a pair of EcoStruxure™ Foxboro™ DCS Fieldbus Modules (FBMs) to select and alarm a single digital input for the control strategy.

The CINR block accepts two digital input values for one input point from redundant FBMs (see Figure 1). The block selects one of these input values for use in the control strategy, depending on a specified input selection option and the quality of the inputs.

The CINR block can optionally be configured to:

- Receive redundant inputs from two other blocks instead of the FBMs for simulation purpose
- Invert the block's input, regardless of the source
- Generate a State Alarm indication and message on any transition of the output
- Invert the meaning of "into alarm" and "return to normal" for State Alarm messages. "Into alarm" comprises a false-to-true transition of the output, and "return-to-normal" is the opposite
- Generate state change messages on only false-to-true or only true-to-false transitions of the output, or on both
- Generate a Bad I/O indication and message when both FBMs or input points have bad status
- Enable configured alarm options to function in the Manual mode
- Suppress nuisance/flutter alarming of all contact input alarms until the alarm deadband timer expires
- Use the last good value or the fallback value for the block contact output when both FBMs or input points are bad or out-of-service
- Re-alarm the active block alarms when the re-alarm timer expires

Figure 1. CINR Block Functional Diagram



Features

Key features of the CINR block are:

- Redundant digital inputs from a pair of FBMs
- Automatic switchover to the secondary input if the primary input is bad
- Manual/Auto transfer, which can be initiated by an operator, a host process, or another block
- Inhibiting of specific types of alarm messages similar to other I/O block types
- Identification of the highest priority among current alarms, indicating alarm type and priority level
- Re-alarms of active block alarms when the alarm priority is changed
- Loop identifier for identifying the loop or process unit that contains the block
- Workstation lock for allowing write access to the block parameters only by the Foxboro DCS FoxView™ session that has locked the block
- Owner identifier for allocating control blocks to applications
- Continuous FBM input monitoring during Manual mode and last good value retention

Block Operation

The CINR block receives redundant input values for a single digital input process point from redundant FBMs (see *Figure 1, page 3*). Based on the quality of the two inputs and the user specification of a default selection, one of the inputs is chosen for use in the control strategy. The state of the selected input is provided to the control strategy as output parameter Contact Input (CIN). It may represent any process contact or discrete logic input. The block also provides alarm handling features relating to the input.

The CINR block offers two basic modes of operation:

- With the FBM Option configured true, block inputs are taken from the FBMs and point number specified by the user
- When the FBM Option is false, the CINR block input is selected from one of two control strategy sources or for simulation.

The block optionally generates bad point alarm messages based on the quality of the two block inputs and state change messages based on transitions of the selected block input.

Messages and Alarms

The CINR block generates the following messages and alarms:

- State Alarm messages contain a user-specified “into alarm” or “return-to-normal” identifying string, and a user-specified Alarm Name as a point descriptor.
- Bad Alarm messages contain the user-specified Bad Alarm Text string.
- State Change messages contain one of two user-specified strings to indicate the direction of transition.

Principal Parameters

Inputs:


- FBM point number (String)
- Primary FBM name (String)
- Secondary FBM name (String)
- Manual/Auto control mode switching (Boolean)
- Redundant inputs from blocks (Boolean).

Outputs:

- Contact input (Boolean)
- Bad I/O alarm indicator (Boolean).

Additional Features

- Delayed alarming. A configurable timer delays alarm detection or return-to-normal messages for a specific alarm to reduce the number of alarm messages generated when a block parameter crosses back and forth over an alarm limit.
- Quality Status output parameter provides a single source for the block's value record status, block status, and alarm status.

 **WARNING:** This product can expose you to chemicals including lead and lead compounds, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.p65warnings.ca.gov/.

Schneider Electric Systems USA, Inc.
38 Neponset Avenue
Foxborough, Massachusetts 02035–2037
United States of America

Global Customer Support: <https://pasupport.schneider-electric.com>

As standards, specifications, and design change from time to time, please ask for confirmation of the information given in this publication.

© 2014–2019 Schneider Electric. All rights reserved.

PSS 41S-3CINR, Rev A