I/A Series[®] Software

Product Specifications

Foxboro_®

by Schneider Electric

PSS 21S-6AIMEXP

AIM*Explorer[™]



AIM*Explorer is a PC desktop tool for visualizing and exploring real-time and historical process data served from I/A Series[®] systems and other data servers. AIM*Explorer features three different window types: Real-time trends (above) that dynamically track up to 16 data objects; charts of historical data from multiple historians; and Batch[™] events that compare completed batches monitored by AIM*Track[™] and the I/A Series Batch Set.

INTRODUCING AIM*EXPLORER

The AIM*Explorer software package allows you to obtain visual displays of historical and real-time process data, including the ability to:

- Create, modify, and save real-time trends from the I/A Series system and other Distributed Control Systems
- Display process information from connected historians in a wide variety of chart formats
- Chart batch events and related process variables sourced from AIM*Track and the I/A Series Batch Set databases
- Monitor up to 16 sources of data simultaneously
- > Zoom into selected areas of any chart
- Switch the chart between normal and banded data presentations

- Select and display charts from reduction group data
- Use a marker bar and a statistical toolbox to examine data in detail
- Time-shift historical chart data and make visual comparisons
- Create various charts to analyze the data
- Define a data transform as a mathematical function of one or more other data sources
- Display the data values and transform results as they are obtained.

AIM*EXPLORER FEATURES

Multiple Chart Styles

AIM*Explorer allows you to build real-time and historical trend charts, bar charts, area charts, or stacked bar charts easily. Each chart style can be further configured with scaling, color, and marker options to show your data with maximum clarity.

Library of Charts

Charts are easily saved and reused with AIM*Explorer. Any trend or chart definition can be saved in a file, used again, and shared with others.

Cut and Paste

AIM*Explorer has the ability to copy trend and spreadsheet data to the Windows[™] clipboard. The Trending Area can be copied either as a bitmap file or metafile. Numerical data or formulas can be copied from the spreadsheet area directly into spreadsheet programs such as Microsoft[™] Excel[™].

Wizards

AIM*Explorer has built-in wizards that can assist you step-by-step in creating a trend or chart.

Windows OLE Support

AIM*Explorer supports the drag-and-drop operation between the Data Object Tree and the Trending Area. You select data sources from the Data Object Tree and drag them into the Trending Area.

Windows Help

AIM*Explorer is supplied with a Microsoft Windows Help file. The Help file contains the complete user's guide with index and keyword search features. In addition, run-time context-sensitive Help is available by clicking the mouse button over an item or by pressing the F1 key.

Windows Registry Support

AIM*Explorer uses the Windows Registry to store the default configuration settings. These settings are used when a new session is started, but can be modified with the Preferences menu.

Windows Style Guidelines

AIM*Explorer has a visual and interactive functionality consistent with the Microsoft Windows operating system – the same functionality that is used in other Windows applications.

Controlled Memory Usage

AIM*Explorer allows you to determine how much data is active in the program via how many data points to collect. When the limit of data points is reached, the next data point collected causes the first data point to be discarded, thereby limiting the set of system resources.

Automatic Screen Management

AIM*Explorer was designed to give the maximum amount of screen area to the actual trending object. In real-time mode, the time-shifting controls disappear to allow the trending object to use more screen area. If you further reduce the size of the window, the list view control likewise becomes invisible, keeping the Trending Area at the maximum possible size, even on the small screens of laptop PCs.

Operations

AIM*Explorer analytical displays use AIM*AT™ servers to access data from three different sources:

- AIM*Explorer trend windows read values in real time from I/A Series data objects using AIM*API™. (When a trend window is started, the immediate history of the selected objects are read from connected historians if the objects are historized).
- Charts derive values from connected AIM*Historian and I/A Series Historian™ instances. For comparative analysis, you can select two time frames for the same objects.
- Batch Event windows display event time lines and associated process variables as monitored by AIM*Track or the I/A Series Batch Suite. When employed with either batch module, AIM*Explorer provides a wizard for accessing selected event data. (Batch Event windows also allow you to relate events to objects selected from connected AIM*Historians).

For trends and charts, you can configure up to 16 data objects (also referred to as pens). The objects can be sourced from either a database point or a mathematical expression that may include any combination of other pens. When you request a data collection, AIM*Explorer gets historical data for the requested time range, performs the specified calculations, and continuously adds the latest real-time and calculated data.

The user interface of AIM*Explorer is made up of four functional components:

- Data Object Tree
- Spreadsheet Area
- Data Object List
- Trending Area.

When the Batch Event option is installed, AIM*Explorer also includes a fifth component, the Segment Browser.

Trend Windows

Descriptions of how the functional components are used to create Trend windows follow.

Data Object Tree

This component allows you to select which data objects to use in the Trending Area. You make your selection from a hierarchical tree showing all the I/A Series servers, stations, and the control object names in those stations (Figure 1) and then copy them to the pens in AIM*Explorer by dragging them to the Data Object List.

Explorer.com - [Analys1]	-
dit <u>V</u> iew <u>S</u> ettings <u>W</u> izards <u>R</u> unTime DataGrid <u>P</u> references <u>W</u> indow <u>H</u> elp	
	_
	- 8
	- 1
ADR-FC501 MEAS	_
ADR-FC502 MEAS	_
ADR-CC04 MEAS	_
BCSIM-FIC14 MEAS	_
BCSIM-FOLIA MEAS	_
BIRIFICIOLINES	- 1
BIR1FC302MEAS	_
BI BI-FC303 MEAS	_
 BLB1-FC304 MEAS 	_
CHEMSIM FICU3 2 MEAS	- 1
CHEMSIM:FIC03 3 MEAS	- 1
CHEMSIM:FIC03 4.MEAS	- 1
CHEMSIM:FIC03_6.MEAS	- 1
COARSE:FIC203.MEAS	- 1
CDARSE:FIC230.MEAS	- 1
CDARSE:FIC244.MEAS	- 1
COARSE:FIC254.MEAS	- 1
- COOLER:FIC_KC0200.MEAS	- 1
- DEB:FC501.MEAS	- 1
• DEB:FC502.MEAS	- 1
DEB:FC504.MEAS	- 1
FLOTATION:FIC301.MEAS	
- • KGR:FIC_KC0251.MEAS	
- • KGR:FIC_KC0252.MEAS	- 1
SPLIT30A:FI101.MEAS	1
o, press F1	NUM



Spreadsheet Area

The spreadsheet component is made up of two worksheets. One worksheet allows you to define mathematical formulas that AIM*Explorer uses for a data pen (Figure 2). The formula can simply display the current value of the object, perform a calculation such as a rolling average and display the result, or combine values from objects connected to other pens. The spreadsheet follows Microsoft Excel conventions for the formula syntax.

FoxExplorer.com - File Edit View Setti	[Reactor 3 ngs <u>W</u> izards	Key Measu <u>R</u> unTime	rements.trd DataGrid <u>P</u> i] eferences y	√indow <u>H</u> el	p					9 ×
	• • •	$\mathcal{O} \oplus \mathbf{f}_*$	<u>99</u>				% № ?				
	Pen 1	Pen 2	Pen 3	Pen 4	Pen 5	Pen 6	Pen 7	Pen 8	Pen 9	Pen 10	
06/06/97 01:23:00	88.851608	73.300446	3.4043007	165.16498	81.076027	38.352373	84.284639	82.582489	0	0	
06/06/97 01:22:59	89.216522	22.611542	3.43471	164.87683	80.914032	38.023126	84.155771	82.438416	0	0	
06/06/97 01:22:58	90.212402	71.840508	3.5177002	164.62016	81.026455	37.679104	84.068932	82.310081	0	0	
06/06/97 01:22:57	90.822342	71.452209	3.5685287	164.50563	81.137276	37.510369	84.03708	82.252815	0	0	
06/06/97 01:22:56	91.999718	70.729225	3.6666431	164.30792	81.364471	37.197934	83.987283	82.153961	0	0	
06/06/97 01:22:55	92.786407	70.151871	3.7322006	164.15675	81.469139	36.942036	83.944477	82.078377	0	0	
06/06/97 01:22:54	92.85701	69.793312	3.7380843	164.0574	81.325161	36.765698	83.897744	82.028702	0	0	
06/06/97 01:22:53	92.557098	69.711723	3.7130914	164.02866	81.134411	36.712407	83.870874	82.014328	0	0	
06/06/97 01:22:52	91.241089	69.757141	3.6034241	164.01569	80.499115	36.680283	83.809555	82.007843	0	0	
06/06/97 01:22:50	89.034569	70.07251	3.4195476	164.0652	79.553539	36.746029	83.742374	82.0326	0	0	
06/06/97 01:22:49	87.660172	70.320374	3.3050141	164.11441	78.990273	36.812694	83.709712	82.057205	0	0	
06/06/97 01:22:48	84.571884	70.958298	3.047657	164.26337	77.765091	37.002977	83.655512	82.131683	0	0	
06/06/97 01:22:47	81.372597	71.719864	2.7810497	164.48138	76.54623	37.250457	83.631217	82.240692	0	0	
06/06/97 01:22:46	78.509445	72.517426	2.5424538	164.76988	75.513435	37.52994	83.656168	82.384941	0	0	
06/06/97 01:22:45	77.340424	72.902634	2.4450355	164.94078	75.121529	37.673835	83.692908	82.47039	0	0	
06/06/97 01:22:44	75.76149	73,598938	2.3134575	165.33594	74.680214	37.956198	83.824697	82.667969	0	0	
06/06/97 01:22:43	75.417252	74.150772	2.284771	165.80182	74.784012	38.217772	84.043295	82.900909	0	0	
06/06/97 01:22:42	75.75499	74.36245	2.3129158	166.06093	75.05872	38.337683	84.186922	83.030464	0	0	
06/06/97 01:22:41	77.448433	74.655655	2.4540362	166.63046	76.052044	38.554846	84,542249	83.315231	0	0	
06/06/97 01:22:40	78.770294	74,742943	2.5641913	166.94034	76.756618	38.653567	84,752265	83.470169	0	0	
06/06/97 01:22:39	82 203804	74.827942	2.850317	167.60861	78.515873	38 839129	85 229465	83.804306	0	0	
06/06/97 01:22:38	86.381195	74.850601	3.1984329	168.33897	80.615898	39.024517	85,768703	84.169487	0	0	
06/06/97 01:22:37	88.61232	74.860382	3.3843598	168,72195	81.736351	39.122371	86.053157	84.360977	0	0	
06/06/97 01:22:36	93.066521	74.923645	3.7555432	169.51186	83.995083	39.339594	86.6337	84.755928	0	0	
06/06/97 01:22:35	97.137695	75.112411	4.0948076	170.32907	86.125053	39.60361	87.211939	85 164536	0	0	
06/06/97 01:22:34	100.45168	75.49231	4.3709726	171.16779	87.971992	39.931641	87.769379	85.583893	0	Ő	
Data / For	mulas /					•					۲Ē
For Help, press F1									[NUM	_

Figure 2. Spreadsheet Formula Entry

The second worksheet shows the data values which are displayed in the Trending Area (including calculations). The data values appear in red if the control object is in an alarm condition, otherwise they appear in black. Calculated values appear in blue (Figure 3).



Figure 3. Spreadsheet Area (shown expanded)

Data Object List

To select objects for use in a Trend window, you drag an object from the Data Object Tree and drop it into the Data Object List, which is displayed above the Trending Area. For each selected object, the Data Object List shows the object source; a description; the current, minimum and maximum values of the object; and the status of alarms configured within the AIM*Explorer application (Figure 4). The Visible attribute in the Data Object List allows you to toggle the display of the object in the Trending Area on and off.

Visible	Data Source	Description	Value	Low	High	Alarm State 🔺
1	P7AW01\TANKS:LAG_20000.LAGTIM		20.00	-10.00	40.00	
2	P7AW01\TANKS:LAG_50000.BIAS		0.00	-10.00	40.00	In Alarm
3	P7AW01\TANKS:LAG_50000.LAGTIM		0.00	0.00	100.00	•
•						•

Figure 4. Data Object List

Trending Area

The Trending Area displays the currently visible pens, and scrolls the data to keep the most current data visible. The user determines which pens are attached to data sources; the visible settings for each data pen; display options for the trend; the scaling factor for each pen; and the time range for data collection. While data collection is active, you can:

- > Zoom in on one part of the graph
- Perform time-shifting operations to compare data at different times
- Obtain real-time statistics
- Freeze the current screen while the data collection continues in the background
- Change each pen's scaling option or value
- Change the time range that is displayed on the trend
- Make pens visible or invisible.

Scaling Options

Individual Pen Options

You can set AIM*Explorer to display each pen on its own individual scale or display all pens using a global scale. The individual scale options are as follows:

 Auto – the maximum and minimum values for the value axis are dynamically determined from the data.

- System Default the maximum and minimum values for the value axis are obtained directly from the I/A Series Object Manager database.
- Hi-Lo you set the maximum and minimum values for the value axis.

Global Pen Options

You can set AIM*Explorer to display the pens in one of the following ways:

- Each Pen Full Screen each visible pen is scaled to use the entire size of the trend's value axis. The maximum and minimum values are set by the individual pen's scaling option.
- Each Pen Non-Full Screen the maximum value for the value axis is set by finding the largest number in each visible pen's current scale. The same is done to determine the minimum value. If the global autoscale option is set, the maximum and minimum values for the value axis are determined dynamically.
- Banding each visible pen is given a range of the value axis. This allows you to see all of the visible pens without any overlap.

When you press a corresponding button on the side of the trend, the value axis displays the pen's maximum and minimum values. When the banding option is activated, these values appear at the top and bottom of that pen's display range on the value axis.

Time Span of Data Collected

There are two factors used to determine the amount of data collected by AIM*Explorer: the Trending Area data and the underlying data store.

Trend Window Data

You set the time span of the Trending Area and the sampling frequency. The number of data points to be displayed in the window is the product of the time span in seconds divided by the sampling frequency.

Data Store

You set a factor that is the number of data points in the underlying data store. The data store is used so that you can time shift the data that is in the Trending Area. The number of points in the data store is the product of the number of points in the Trending Area data set multiplied by the data store factor.

Chart Windows

AlM*Explorer Chart windows are used to display process information sourced from connected AlM*Historians and other databases. Charts use the same components as Trend windows, but allow additional flexibility in selecting and analyzing process data. For example, the same object can be assigned to multiple pens so you can compare the values of different time frames. Slider bars for each time frame allow you to shift the data in one time frame independently or in relation to the other time frame. Figure 5 shows an AlM*Explorer Chart using two time frames for time-shifted analysis.



Figure 5. Chart with Two Time-Shifting Sliders

Chart formats (Figure 6) include two- and threedimensional stacks, boxes, and filed areas. Threedimensional stacks can be rotated and tilted forward to enhance perspective on the historical data.



Figure 6. Typical Chart Formats

Batch Event Windows

When the Batch Event option is installed, AIM*Explorer includes the Segment Browser compnent, which is similar to the Data Object Tree. The browser shows a hierarchy of batches, events, and related process variables defined in an AIM*Track or I/A Series Batch Set database (Figure 7).

AIM^Explorer - [Batch I]
貯 Eile Edit View Settings Wizards RunTime DataGrid Preferences Window Help
D≊∎♂₽�⊼‼≦®
😑 🧀 All Batches
🖕 🗁 B110399111929 (89856) 11/3/99 11:27:59 AM => 11/3/99 11:28:20 AM
AIMSRV/TANKS:T_100.PNT
AIMSRV/TANKS:T_101.PNT
AIMSRV/TANKS:T_102.PNT
AIMSRV/TANKS:T 200.PNT
AIMSRV/TANKS:T 201.PNT
AIMSBV/TANKS:T 202.PNT
E B110399111929 (89857) 11/3/99 11:29:09 AM => 11/3/99 11:30:35 AM
AIMSRV/TANKS:T 100.PNT
AIMSBV/TANKS:T 101.PNT
AIMSBV/TANKS:T 102.PNT
AIMSBV/TANKS T 200 PNT
AIMSBV/TANKS T 201 PNT
AIMSBV/TANKS T 202 PNT
■ B110399111929 (90112) 11/3/99 2:30:39 PM => 11/3/99 2:34:18 PM

Figure 7. Segment Browser

To display batch events, you drag objects from the Segment Browser and drop them in the Data Object List. You can also add objects from the Data Object Tree and associate them with a batch.

Batch Event Trending Area Display

In a Batch Event window, the Trending Area displays the selected batch events on a time line and shows the changes with the associated process variable during each batch. You can arrange the display into separate bands for each data item, or plot the process variables on the batch event time lines. The batch events are identified with callouts based on definitions in the AIM*Track or I/A Series Batch Set database. You can selectively enable these callouts to determine their positions and modify the style to enhance your understanding of the display.

Figure 8 shows a banded Trending Area display with callouts identifying events on two batch event time lines.



Figure 8. Banded Batch Events Display

Notes and Other Tools

In Batch Event windows, two worksheets are added to the spreadsheet tool in the upper right corner of the window: Batch Events and Batch Notes.

The Batch Events sheet lists events in the selected batch using information defined in the AIM*Track or I/A Series Batch Set database.

The Batch Notes sheet lists annotations which you and other users append to displayed batch events. AIM*Explorer provides an easy-to-use dialog box for entering notes and reviewing previous annotations.

Batch Event windows also include on-screen tools for measuring elapsed time between events and between events and variables reaching a specified value (Figure 9).



Figure 9. Time Marking in a Batch Event Display

EASE OF USE FEATURES

Registry Settings

The following parameters are stored in the Windows Registry to be used as the default settings:

- Axis Mode
- Pen Characteristics
- Time Axis Settings
- Chart Settings
- Spreadsheet Settings
- Data Store Factor.

You can save the current settings as new default settings any time.

Stored Setups

Each trend, chart, and batch event window can be saved to a file for later analysis, for export to other users, and as a template for similar applications. In addition to the data store, the file includes the object view, the data object selections, calculations, and Trending Area formatting. When you access a saved window, AIM*Explorer assists you in displaying the saved data, starting a new data collection, or modifying the setup.

Data Object Wizard

The built-in Data Object Wizard is a step-by-step guide for specifying data object views. A view is a set of process data objects from one or more I/A Series servers. Figure 10 shows an example of the wizard. In this example, a user has specified data from one control processor. Note the use of a filter to select particular station names (stations beginning with C).

Main I/A Server Filter
C* Filter Filter
□ AWOPER □ CP3051 □ CP4050 □ CP4050 □ P7AW01 □ CPC301 □ CPC302 □ CSC101
< <u>B</u> ack <u>N</u> ext > Cancel Help

Figure 10. Wizard Example with Station Filter

Filtering can also be used to select compound or block names from I/A Series systems. Figure 11 shows a wizard which is filtering for I/A Series block names that begin with FC.



Figure 11. Wizard Example with Block Name Filter

Segment Browser Wizard

The Segment Browser Wizard provides a series of database query filters to select data from an AIM*Track or I/A Series Batch Set database. The selected data items are displayed in the Segment Browser. Similar to the Data Object Wizard, this tool allows you to construct a query using multiple criteria, and then make a final selection of data items from the returned values. Figure 12 shows a filter page in the wizard for selecting data items based on equipment defined in the AIM*Track or I/A Series Batch Set database.

Segment Browser Wizard (Ploymer)
Main Time Span Equipment Procedure Tagnames Query Results
Filter Selection Select node only Show Selected Expand Collapse Select All Clear All Use OR between Equipment & Procedure Evand Collapse Select All Clear All
Total Equipment: 70 Total Selected: 6
Image: Convergent of the state of the s
Select DISTINCT binternal_batch_id, b.batch_id, b.product_id, b.campaign_id, b.description from batch_occ, tol b where binternal_batch_id in (select distinct a internal_batch_id from event, occ, tol a where binternal_batch_ot of the patch distinct and the patch distinct a internal_batch_id from event, occ, tol a where binternal_batch_ot of the patch distinct and th
Kack Next> Emit

Figure 12. Segment Browser Wizard Equipment Page

Supported Platforms

AIM*Explorer is a client application that operates on a PC running Microsoft Windows 95[™], Windows 98[™] or Windows NT[™] 4.0.

AIM*Explorer accesses real-time and historical data using an AIM*AT server, which can be on the same host or linked to the AIM*Explorer platform via a TCP/IP connection. The AIM*AT server provides the client authorization and access to connected I/A Series control databases, Historian instances, and AIM*Track and I/A Series Batch Set databases. A single AIM*Explorer instance can be used to access multiple properly licensed AIM*AT servers.

To display AIM*Track event information, AIM*Explorer requires the AIM*Track Segment Browser installed on the same platform and authorized network access to the AIM*Track segment database.

To display I/A Series Batch Set event information, AIM*Explorer requires the I/A Series Batch Segment Browser installed on the same platform and authorized network access to the I/A Series Batch Set database.

PSS 21S-6AIMEXP Page 11



by Schneider Electric

Invensys Systems, Inc 10900 Equity Drive Houston, TX 77041 United States of America http://www.invensys.com

Global Customer Support Inside U.S.: 1-866-746-6477 Outside U.S.: 1-508-549-2424 Website: https://support.ips.invensys.com MB 021

Copyright 2014 Invensys Systems, Inc. All rights reserved. Invensys is now part of Schneider Electric.

Invensys, Foxboro, and I/A Series are trademarks owned by Invensys Limited, its subsidiaries and affiliates. All other trademarks are the property of their respective owners.