

Preferred Products

Listing for Master Book 031/21A - Foxboro Evo Process Automation System

The Product Specification Sheets listed are for products that are in the Preferred Phase of their lifecycle. These documents represent standard hardware and software products that are the most recent products in their functional areas.

A system composed of Foxboro Evo and I/A Series hardware and software may be assembled from these preferred products as described in the documentation.

NOTE: PSS numbers in the Foxboro Evo Preferred PSS listing have changed and the titles refer to the PSS number that has been superseded.

FOXBORO EVO PROCESS AUTOMATION SYSTEM

Document No.	Title	Date
--------------	-------	------

FOXBORO EVO SYSTEM HARDWARE

Control Stations

PSS 21H-1B9	Field Control Processor 270 (FCP270) (Supersedes: PSS 21H-1B9 B3)	0216
PSS 21H-1B10	Z-Module Control Processor 270 (ZCP270) (Superseded: PSS 21H-1B10 B3)	1214
PSS 31H-1ATS	Address Translation Station Communications (Supersedes: PSS 21H-1C4 B3)	1214
PSS 31H-1CNI	Control Network Interface	0118
PSS 31H-1FCP280	Field Control Processor 280 (FCP280) (Supersedes: PSS 31H-1B11 B3, PSS 21H-1B11 B3)	0518
PSS 31H-2FDP280	Field Device Controller (FCP280)	1117

Standard and Compact 200 Series Subsystems (DIN Rail Fieldbus Modules)

PSS 21H-2Y10 B4	FCM100Et Redundant Fieldbus Communications Module	0613
PSS 21H-2Y11 B4	FCM100E Redundant Fieldbus Communications Module Intrinsically Safe Termination Assembly - Base Plate (ISTA-*BP*)	1111
PSS 31H-2CERTS	Standard and Compact 200 Series I/O, Agency Certifications (Supersedes: PSS 31H-2W2 B3)	0917
PSS 31H-2C200	Compact 200 Series 16-Slot Horizontal Baseplate (Supersedes: PSS 31H-2C200 B4)	1215
PSS 31H-2C201	Compact FBM201 Analog Input 0 to 20 mA Interface Module	0816
PSS 31H-2C202	Compact FBM202, Thermocouple/mV Input Modules	0816
PSS 31H-2C203	Compact FBM203 Platinum/Nickel/Copper RTD Input Module	0816
PSS 31H-2C204	Compact FBM204, 0 to 20 mA I/O Module	0416

FOXBORO EVO PROCESS AUTOMATION SYSTEM

Document No.	Title	Date
PSS 31H-2C207	Compact FBM207b Contact Sense Input Interface Modules (Supersedes: PSS 31H-207 B4)	0518
PSS 31H-2C208	Compact FBM208, Redundant with Readback, 0 to 20 mA I/O Module	0316
PSS 31H-2C211	Compact FBM211, 0 to 20 mA Input Module	0816
PSS 31H-2C212	Compact FBM212 Thermocouple/mV Differential Input Module	0316
PSS 31H-2C214	Compact FBM214b HART Communication Input Interface Module (Supersedes: PSS 31H-2C214 B4)	0816
PSS 31H-2C215	Compact FBM215, HART Communication Output Interface Module (Supersedes: PSS 31H-2C215 B4)	0816
PSS 31H-2C216	Compact FBM216b HART Communication Redundant Input Interface Module (Supersedes: PSS 31H-2C16 B4)	0816
PSS 31H-2C217	Compact FBM217 Discrete Input Module	0816
PSS 31H-2C218	Compact FBM218 HART Communication Redundant Output Interface Module (Supersedes: PSS 31H-2C218 B4)	0816
PSS 31H-2C219	Compact FBM219 Discrete I/O Interface Module	1115
PSS 31H-2C227	Compact FBM227, 0 to 10 V dc, Contact/dc I/O Module with DPIDA and MDACT Support	1115
PSS 31H-2C237	Compact FBM237, 0 to 20 mA Output Module (Redundant Ready)	0816
PSS 31H-2C238	Compact FBM238, Digital 24DI/8DO Module	1115
PSS 31H-2C239	Compact FBM239, Digital 16DI/16DO Module	1115
PSS 31H-2C240	Compact FBM240, Redundant with Readback, Discrete Output and Discrete Input Module	0816
PSS 31H-2C241	Compact FBM241/c Discrete I/O Modules	0818
PSS 31H-2C242	Compact FBM242, Externally Sourced, Discrete Output Interface Module (Supersedes: PSS 31H-2C242 B4)	0816

FOXBORO EVO PROCESS AUTOMATION SYSTEM

Document No.	Title	Date
PSS 31h-2C247	Compact FBM247, Current/Voltage Analog/Digital/Pulse I/O Configurable Module	0918
PSS 31H-2C248	Compact 248, Current/Voltage Analog/Digital/Pulse I/O Configurable Module, Redundant	0918
PSS 31H-2C480 B4	Compact Power Supply - FPS480-24	0414
PSS 31H-2COV	Compact 200 Series I/O Subsystem Overview (Supersedes: PSS 31H-2COV B3)	0917
PSS 31H-2FBI200	FBI200 Fieldbus Isolator/Filter (Supersedes: PSS 31H-2Y18)	0317
PSS 31H-2FCM	Fieldbus Communications Module, FCM2F2/FCM2F4/FCM2F10 (Supersedes: PSS 31H-2Y3, PSS 21H-2Y3 B3)	0718
PSS 31H-2FDC280	Field Device Controller 280 (FDC280)	1117
PSS 31H-2FEM100	FEM100 Fieldbus Expansion Module	1215
PSS 31H-2FPS	200 Series Power Supplies - FPS240-24 and FPS120-24 (Supersedes: PSS 31H-2W7 B4, PSS 21H-2W7 B4)	0916
PSS 31H-2FPS400	Standard 200 Series Power Supply - FPS400-24 (Supersedes: PSS 31H-2W3)	1215
PSS 31H-2S201	FBM201/b/c/d Analog Input (0 to 20 mA, 0 to 100 mV, 0 to 5 V, 0 to 10 V dc) (Supersedes: PSS 31H-2Z1)	0816
PSS 31H-2S202	FBM202 Thermocouple/mV Input Module (Supersedes: PSS 31H-2Z2)	0918
PSS 31H-2S203	FBM203/b/c/d Platinum/Nickel/Copper RTD Input Module (Supersedes: PSS 31H-2Z3)	0918
PSS 31H-2S204	FBM204, 0 to 20 mA I/O Module (Supersedes: PSS 31H-2Z4)	0816
PSS 31H-2S205	FBM205, 0 to 20 mA I/O Interface Module (Redundant) (Supersedes: PSS 21H-2Z5 and PSS 31H-2Z5)	0816
PSS 31H-2S206	FBM206 Pulse Input Module (Supersedes: PSS 31H-2Z6)	0816
PSS 31H-2S207	FBM207/b/c Voltage Monitor/Contact Sense Input Modules (Supersedes: PSS 31H-2Z7)	0816

FOXBORO EVO PROCESS AUTOMATION SYSTEM

Document No.	Title	Date
PSS 31H-2S208	FBM208, Redundant with Readback, 0 to 20 mA I/O Module (Supersedes: PSS 31H-2Z28)	0816
PSS 31H-2S211	FBM211, 0 to 20 mA Input Module (Supersedes: PSS 31H-2Z211)	0816
PSS 31H-2S212	FBM212 Thermocouple/mV Differential Input Module (Supersedes: PSS 21H-2Z12 B4 and PSS 31H-2Z12)	0816
PSS 31H-2S214	FBM214b HART Communication Input Module (Supersedes: PSS 31H-2Z14)	0816
PSS 31H-2S215	FBM215 HART Communication Output Module (Supersedes: PSS 21H-2Z15 B4 and PSS 31H-2Z15)	0816
PSS 31H-2S216	FBM216b Redundant HART Communication Input Module (Supersedes: PSS 31H-2Z16)	0816
PSS 31H-2S217	FBM217 Discrete Input Module (Supersedes: PSS 31H-2Z217)	1116
PSS 31H-2S218	FBM218 HART Communication Redundant Output Module (Supersedes: PSS 31H-2Z18)	0816
PSS 31H-2S219	FBM219 Discrete I/O Module (Supersedes: PSS 31H-2Z19)	0816
PSS 31H-2S222	FBM222, Redundant PROFIBUS Communication Module (Supersedes: PSS 31H-2Z22, PSS 21H-2Z22 B4)	0816
PSS 31H-2S227	FBM227, 0 to 10 V dc, Contact/dc I/O Module with DPIDA and MDACT Support (Supersedes: PSS 31H-2Z27 and PSS 21H-2Z27 B4)	0816
PSS 31H-2S228	FBM228 FOUNDATION fieldbus Module for Control in the Field Applications	1017
PSS 31H-2S229	FBM229 DeviceNet Communication Module (Supersedes: PSS 31H-2Z29)	0816
PSS 31H-2S230	FBM230 Field Device System Integrator Module, Four Serial Ports, Single (Supersedes: PSS 31H-2Z30)	0816
PSS 31H-2S231	FBM231 Field Device System Integrator Module, Four Serial Ports, Redundant (Supersedes: PSS 31H-2Z31)	0816
PSS 31H-2S232	FBM232 Field Device System Integrator Module, 10/100 Mbps Ethernet, Single (Supersedes: PSS 21H-2Z32 B4 and PSS 31H-2Z32)	0816
PSS 31H-2S233	FBM233 Field Device System Integrator Module, 10/100 Mbps Ethernet, Redundant (Supersedes: PSS 21H-2Z33 B4 and PSS 31H-2Z33)	0816

FOXBORO EVO PROCESS AUTOMATION SYSTEM

Document No.	Title	Date
PSS 31H-2S237	FBM237, 0 to 20 mA Output Module (Redundant Ready) (Supersedes: PSS 21H-2Z37 B4 and PSS 31H-2Z37)	0816
PSS 31H-2S238	FBM238, Digital 24DI/8DO Module (Supersedes: PSS 31H-2Z38 and PSS 21H-2Z38 B4)	0816
PSS 31H-2S239	FBM239, Discrete 16DI/16DO Module (Supersedes: PSS 31H-2Z39 and PSS 21H-2Z39 B4)	0816
PSS 31H-2S240	FBM240, Redundant with Readback, Discrete Output Module (Supersedes: PSS 21H-2Z40 B4 and PSS 31H-2Z40)	0117
PSS 31H-2S241	FBM241/b/c/d Discrete I/O Modules (Supersedes: PSS 31H-2Z41 and PSS 21H-2Z41 B4)	0818
PSS 31H-2S242	FBM242, Externally Sourced, Discrete Output Module (Supersedes: PSS 21H-2Z42 B4 and PSS 31H-2Z42)	0816
PSS 31H-2S243	FBM243/b, FoxCom Dual Baud Rate, Intelligent Device Modules (Supersedes: PSS 31H-2Z43 and PSS 21H-2Z43 B4)	0317
PSS 31H-2S244	FBM244, 0 to 20 mA I/O Module with HART Support (Supersedes: PSS 31H-2Z44 and PSS 21H-2Z44 B4)	0816
PSS 31H-2S245	FBM245, 0 to 20 mA I/O Module with HART Support (Redundant) (Supersedes: PSS 31H-2Z45 and PSS 21H-2Z45 B4)	0816
PSS 31H-2S246	FBM246/b, FoxCom Redundant Dual Baud Rate, Intelligent Device Modules (Supersedes: PSS 31H-2Z46 and PSS 21H-2Z46 B4)	0816
PSS 31H-2S247	FBM247, Current/Voltage Analog/Digital/Pulse I/O Configurable Module (Supersedes: PSS 31H-2Z47 and PSS 21H-2Z47 B4)	0918
PSS 31H-2S248	FBM248, Current/Voltage Analog/Digital Pulse I/O Configurable Module	0918
PSS 31H-2SBASPLT	Standard 200 Series Baseplates	1016
PSS 31H-2SOV	Standard 200 Series Subsystem Overview (Supersedes PSS 21H-2W1 B3)	0516
PSS 31H-2W4	Termination Assembly Adapter Modules for 100 Series Upgrade (Supersedes: PSS 21H-2W4 B4)	1114
PSS 31H-2W8	100 Series Conversion Mounting Structures (Supersedes: PSS 21H-2W8 B4)	1014

FOXBORO EVO PROCESS AUTOMATION SYSTEM

Document No.	Title	Date
PSS 31H-2W12 B3	DIN Rail Mounted High Density I/O Equipment, Agency Certifications	0414
PSS 31H-2W100	100 Series Fieldbus Module Upgrade Subsystem Overview (Supersedes: PSS 21H-2W1 B4)	1215
PSS 31H-2Y6	Intrinsically Safe I/O Subsystem	0116
PSS 31H-2Y14	FEM100 Fieldbus Expansion Module (Supersedes: PSS 21H-2Y14 B4)	1014
PSS 31H-2Y17	FBI200A Fieldbus Isolator/Filter (Supersedes: PSS 21H-2Y17 B4)	1014

FBM Migration Modules

PSS 31H-3A2	DCS FBM for Migration of Fisher PROVOX Systems (Supersedes: PSS 21H-3A2 B3)	1014
PSS 31H-3A3	DCS FBM for Migration of Bailey Systems (Supersedes: PSS 21H-3A3 B3)	0416
PSS 31H-3A4	DCS FBM for Westinghouse Process Control WDPF I and II Systems (Supersedes: PSS 21H-3A4 B3)	1014
PSS 31H-3A5	DCS Fieldbus Modules for Siemens APACS+ Automation Systems (Supersedes: PSS 21H-3A5 B3)	1214
PSS 31H-3HON	Honeywell Systems Migration Modules (Supersedes: PSS 21H-3A1 B3)	0914

Industrial Workstation and Devices

PSS 21H-4B1B3	Hard Copy Devices	0613
PSS 21H-4B4B4	Color PCL3 Printer	0608
PSS 21H-4B6B4	Color PostScript Printer	0609
PSS 21H-4B10B4	Digital Color Printer	0613
PSS 21H-4B11B4	80-Column Black and White Dot-Matrix Printer	0613
PSS 21H-4D6B4	20-Inch Workstation Display With/Without Touchscreen	0397

FOXBORO EVO PROCESS AUTOMATION SYSTEM

Document No.	Title	Date
PSS 21H-4D14B4	WorkCenter for I/A Series Stations	0811
PSS 21H-4N1B3	Invensys Process Magnetic Resonance Analyzer Mode NMRC	0606
PSS 21H-4THNCLNT	Thin Clients	0118
PSS 31H-3E2	Redundant Array of Independent Disks (Supersedes: PSS 21H-3E2 B4)	1014
PSS 31H-4B3	Dot-Matrix Printer 80 (Supersedes: PSS 21H-4B3 B4)	1014
PSS 31H-4B5	132-Column Color Dot-Matrix Printer (Supersedes: PSS 21H-4B5 B4)	1014
PSS 31H-4C2	Time Synchronization Equipment (Supersedes: PSS 21H-4C2 B3)	0518
PSS 31H-4H90	Model H90 Workstation Server for Windows Server 2008 R2 Operating System (Supersedes: PSS 21H-4U12 B4)	1017
PSS 31H-4H90	Model H90 Workstation Server for Windows Server 2016 Operating System	0318
PSS 31H-4H92	Model H92 Workstation for Windows 7 Professional Operating System (Supersedes: PSS 31H-4D13)	0317
PSS 31H-4H92	Model H92 Workstation for Windows 10 Operating System	0318
PSS 31H-4M90	Model M90 (P0928KM) Server for Windows Server 2008 R2 Operating System	0716
PSS 31H-4M92	Model M92 (P0928KK) Workstation with Windows 7 Professional Operating System	0716
PSS 31H-4USBKBD	Annunciator Keyboard (Supersedes PSS 21H-4E1 B4)	0715
PSS 31H-4V90	Virtualization server Host Hardware Model V90	0515
PSS 31H-4V91	Virtualization server Host Hardware Model V91	0818
PSS 31H-4VDU	Liquid Crystal Display (LCD) Monitors (Supersedes: PSS 21H-4D10 B4)	0617

FOXBORO EVO PROCESS AUTOMATION SYSTEM

Document No.	Title	Date
Enclosures		
PSS 31H-2G06	Global Enclosure G06	1014
PSS 31H-2G10	G10 System Enclosure (Supersedes: PSS 21H-2X8B4)	1014
PSS 31H-2G11	G11 Termination Enclosure (Supersedes: PSS 31H-2G11 B4, PSS 21H-2X9 B4)	1014
PSS 31H-2G12	G12 System and Termination Enclosure (Supersedes: PSS 21H-2X10 B4)	1014
PSS 31H-2G13	G13 System Enclosure (Supersedes: PSS 31H-2G13 B4)	1214
PSS 31H-2G14	G14 System and Termination Enclosure	1014
PSS 31H-2G15	G15 System Enclosure (Supersedes: PSS 21H-2X15 B4)	1014
PSS 31H-2G16	G16 Termination Enclosure (Supersedes: PSS 21H-2X16 B4)	1014
PSS 31H-2G17	G17 System and Termination Enclosure (Supersedes: PSS 21H-2X17 B4)	1014
PSS 31H-2G20	G20 System Enclosure (Supersedes: PSS 21H-2X12 B4)	1014
PSS 31H-2G21	G21 Termination Enclosure (Supersedes: PSS 21H-2X13 B4)	1014
PSS 31H-2G22	G22 System and Termination Enclosure (Supersedes: PSS 21H-2X14 B4)	1014
PSS 31H-2G40	G40 19-Inch Rack Enclosure (Supersedes: PSS 21H-2X40 B4)	1214
PSS 31H-2G45	G45 19-Inch Rack Enclosure (Supersedes: PSS 21H-2X45 B4)	1214
PSS 31H-2G50	G50 Server Enclosure (Supersedes: PSS 21H-2X50 B4)	1214
PSS 31H-2G60	G60 Tricon System Enclosure (Supersedes: PSS 21H-2X60 B4)	1114
PSS 31H-2G61	G61 Tricon Termination Enclosure (Supersedes: PSS 21H-2X61 B4)	1114
PSS 31H-2G62	G62 and G72 Tricon System and Termination Enclosures (Supersedes: PSS 21H-2X62 B4)	1114

FOXBORO EVO PROCESS AUTOMATION SYSTEM

Document No.	Title	Date
PSS 31H-2G66	G66 Tricon Termination Enclosure (Supersedes: PSS 21H-2X66 B4)	1114
PSS 31H-2G80	G80 Trident Enclosure (Supersedes: PSS 21H-2X80 B4)	1114
PSS 31H-2G85	G85 Trident Enclosure (Supersedes: PSS 21H-2X85 B4)	1114
PSS 31H-2GOV	G-Series Enclosures Overview (Supersedes: PSS 31H-2GOV B3)	1014
PSS 31H-2K06	K06 Wall Mount Enclosure	0815
PSS 31H-2K10	K10 System Enclosure	0815
PSS 31H-2K11	K11 Termination Enclosure	0815
PSS 31H-2K12	K12 System and Termination Enclosure	0815
PSS 31H-2K13	K13 System Enclosure	0815
PSS 31H-2K14	K14 System and Termination Enclosure	0815
PSS 31H-2K15	K15 System Enclosure	0815
PSS 31H-2K16	K16 Termination Enclosure	0815
PSS 31H-2K17	K17 System and Termination Enclosure	0815
PSS 31H-2K20	K20 System Enclosure	0815
PSS 31H-2K21	K21 Termination Enclosure	0815
PSS 31H-2K22	K22 System and Termination Enclosure	0815
PSS 31H-2K40	K40 19-Inch Rack Enclosure	0916
PSS 31H-2K45	K45 19-Inch Rack Enclosure	0916
PSS 31H-2K50	K50 Server Enclosure	0815

FOXBORO EVO PROCESS AUTOMATION SYSTEM

Document No.	Title	Date
PSS 31H-2K60	K60 Tricon System Enclosure	0516
PSS 31H-2K61	K61 Tricon Termination Enclosure	0516
PSS 31H-2K62	K62 and K72 Tricon System Termination Enclosures	0516
PSS 31H-2K66	K66 Tricon Termination Enclosure	0516
PSS 31H-2K80	K80 Trident Enclosure	0516
PSS 31H-2K85	K85 Trident Enclosure	0516
PSS 31H-2KOV	K-Series Enclosures Overview	0916
Communications		
PSS 21H-7R1B3	SPEC 200 Control Integrators	0313
PSS 21H-7R2B3	SPEC 200 MICRO Control Integrators	0313
PSS 31H-7NETWORK	The Foxboro Evo Control Network Architecture (Supersedes: PSS 21H-7C2 B3)	0917
PSS 31H-7NwEquip	The Foxboro Evo Control Network Ethernet Equipment (Supersedes: PSS 31H-7C3 B4, PSS 31H-7NW_EQUIP)	0818
PSS 31H-7SMI	SPECTRUM Migration Integrators (Supersedes: PSS 21H-7Q1 B3)	1114
PSS 31H-7SMIEXP	SPECTRUM Migration Integrator Expert (Supersedes: PSS 21H-7Q2 B3)	1014

FOXBORO EVO PROCESS AUTOMATION SYSTEM

Document No.	Title	Date
--------------	-------	------

FOXBORO EVO SYSTEM SOFTWARE

Workstation Software

PSS 21S-1B10B3	Workstation Server for Windows 2003 Software Overview Microsoft Windows Server 2003 Operating System	0806
PSS 21S-2B5B4	I/A Series Configuration Component (IACC) Engineering Package for Windows 7 and Window Server 2008 Professional Edition	0114
PSS 31S-1IACC	I/A Series Configuration Component (IACC) Engineering Package for Windows 10 and Window Server 2016	0318
PSS 21S-4INBATCH	InBatch 2014 R3 (v11.5)	0916
PSS 21S-8A3B3	Intelligent Field Device Configurator FoxCom and HART Protocols	0602
PSS 21S-8A9B3	Overview of Hypervisor Technology - Microsoft Hyper-V Hypervisor	0413
PSS 31S-1TIME	Time Synchronization Overview	0518
PSS 31S-2B2	FoxAlert Alarm Manager (Supersedes: PSS 21S-2B2 B4)	1214
PSS 31S-2B3	FoxDraw Display Builder and Configurator (Supersedes: PSS 21S-2B3 B4)	1114
PSS 31S-2B7	FoxPanels Configurator and Run-Time Software (Supersedes: PSS 21S-2B7 B4)	1114
PSS 31S-2B8	FoxView Software (Supersedes: PSS-21S-2B8 B4)	1114
PSS 31S-2NETSITE	NetSight Console for Use with The MESH Control Network (Supersedes: PSS 21S-2B13 B4 and PSS 31S-2NETSIGHT)	0217
PSS 31S-2SOE	Sequence of Events (Supersedes: PSS 21S-2B9 B4)	0215
PSS 31S-2TDRA	Transient Data Recorder and Transient Data Analyzer (Supersedes: PSS 21S-2B10B4)	0917
PSS 21S-4INBATCH	InBatch 2014 R3 (v11.5)	0916
PSS 31S-4MCAFEE	McAfee Security Products	0917

FOXBORO EVO PROCESS AUTOMATION SYSTEM

Document No.	Title	Date
PSS 31S-4PHYSPRP	Physical Properties Library (Supersedes: PSS 21S-4C1 B3 and PSS 31S-4PHYSPROP)	0615
PSS 31S-4SFCCFG	Sequential Function Chart/Structured Text (SFC/ST) Configurator and Display Manager (Supersedes: PSS 21S-4V2 B3)	1214
PSS 31S-4SYMANTC	Symantec Endpoint Protection	0816
PSS 31S-4SYSAUD	System Auditor	1217

Control and I/O Software

PSS 21S-3A7B3	Modbus Master (Serial and TCP/IP) for Field Device System Integrator Modules	1204
PSS 21S-3A8B3	OPC Client Driver for Field Device System Integrator Modules	1204
PSS 31S-3A9 B3	FDSI Triconex Integrator Driver for Field Device System Integrator Modules (Supersedes: PSS 21S-3A9 B3)	0614
PSS 21S-3A10B3	FDSI Ethernet/IP Driver for Field Device System Integrator (FDSI) Modules	0109
PSS 21S-3CP270IC	Control Processor 270 (CP270) Integrated Control Software (Supersedes: PSS 21S-3CP270ICS, PSS 21S-3B2 B3)	0615
PSS 31S-3ACCUM	Accumulator (ACCUM) Block (Supersedes: PSS 21S-3B3 B4)	0914
PSS 31S-3AIN	Analog Input (AIN) Block (Supersedes: PSS 21S-3G9 B4)	0914
PSS 31S-3AINR	Redundant Analog Input (AINR) Block (Supersedes: PSS 21S-3L1 B4)	0914
PSS 31S-3ALMPRI	Alarm Priority (ALMPRI) Change Block (Supersedes: PSS 21S-3B5 B4)	0914
PSS 31S-3AOUT	Analog Output (AOUT) Block (Supersedes: PSS 21S-3H1 B4)	0914
PSS 31S-3AOUTR	Redundant Analog Output (AOUTR) Block (Supersedes: PSS 21S-3L2 B4)	0914
PSS 31S-3BIN	Binary Input (BIN) Block (Supersedes: PSS 21S-3N6 B4)	0914
PSS 31S-3BINR	Redundant Binary Input (BINR) Block (Supersedes: PSS 21S-3N11 B4)	0914

FOXBORO EVO PROCESS AUTOMATION SYSTEM

Document No.	Title	Date
PSS 31S-3BLNALM	Boolean Alarm (BLNALM) Block (Supersedes: PSS 21S-3B9 B4)	0914
PSS 31S-3BOUT	Binary Output (BOUT) Block (Supersedes: PSS 21S-3N7 B4)	0914
PSS 31S-3BOUTR	Redundant Binary Output (BOUTR) Block (Supersedes: PSS 21S-3N13 B4)	0914
PSS 31S-3CALC	Calculation (CALC) Block (Supersedes: PSS 21S-3B7 B4)	0914
PSS 31S-3CALCA	Advanced Calculator (CALCA) Block (Supersedes: PSS 21S-3M8 B4)	0914
PSS 31S-3CHARC	Characterizer (CHARC) Block (Supersedes: PSS 21S-3C1 B4)	0914
PSS 31S-3CIN	Contact Input (CIN) Block (Supersedes: PSS 21S-3H3 B4)	0914
PSS 31S-3CINR	Redundant Contact Input (CINR) Block (Supersedes: PSS 21S-3H4 B4)	0914
PSS 31S-3COUT	Contact Output (COUT) Block (Supersedes: PSS 21S-3H5 B4)	0914
PSS 31S-3COUTR	Redundant Contact Output (COUTR) Block (Supersedes: PSS 21S-3H8 B4)	0914
PSS 31S-3DATVAR	Data Variable Block (Supersedes: PSS 21S-3N2 B4)	0914
PSS 31S-3DGAP	Differential Gap (DGAP) Controller Block (Supersedes: PSS 21S-3C5 B4)	0914
PSS 31S-3DPIDA	Distributed PIDA (DPIDA) Controller (Supersedes: PSS 21S-3N4 B4)	0914
PSS 31S-3DTIME	Dead Time (DTIME) Block (Supersedes: PSS 21S-3C3 B4)	0914
PSS 31S-3EVENT	Event (EVENT) Block (Supersedes: PSS 21S-3C9 B4)	0518
PSS 31S-3EXACT	EXACT Multivariable Control (EXACT MV) (Supersedes: PSS 21S-3A2 B3)	0914
PSS 31S-3FBTUNE	Feedback Tuner (FBTUNE) Block (Supersedes: PSS 21S-3L3 B4)	0914
PSS 31S-3FCPICS	Field Control Processor 280 (CP280) Integrated Control Software (Supersedes: PSS 31S-3B3 B3, PSS 21S-3B3 B3)	0914
PSS 31S-3FDCMBDV	Modbus Master TCP Driver for Field Device Controller 280	1016

FOXBORO EVO PROCESS AUTOMATION SYSTEM

Document No.	Title	Date
PSS 31S-3FFTUNE	Feedforward Adaptor (FFTUNE) Block (Supersedes: PSS 21S-3L4 B4)	0914
PSS 31S-3GDEV	Generic Device (GDEV) Block (Supersedes: PSS 21S-3C7 B4)	0914
PSS 31S-3IINR	Redundant Integer Input (IINR) Block (Supersedes: PSS 21S-3Q14 B4)	1214
PSS 31S-3LIM	Positional/Rate Limiter (LIM) Block (Supersedes: PSS 21S-3F7 B4)	0914
PSS 31S-3LLAG	Lead-Lag (LLAG) Block (Supersedes: PSS 21S-3D1 B4)	0914
PSS 31S-3LOGIC	Logic (LOGIC) Block (Supersedes: PSS 21S-3L5 B4)	0914
PSS 31S-3MCOUT	Multiple Contact Output (MCOUT) Block (Supersedes: PSS 21S-3E3 B4)	0914
PSS 31S-3MDACT	Motor Driven Actuator (MDACT) Block (Supersedes: PSS 21S-3L7 B4)	1214
PSS 31S-3MEALM	Measurement Alarm (MEALM) Block (Supersedes: PSS 21S-3L8 B4)	1214
PSS 31S-3MOVLV	Motor Operated Valve (MOVLV) Block (Supersedes: PSS 21S-3D5 B4)	0914
PSS 31S-3MROUT	Multiple Real Output (MROUT) Block (Supersedes: PSS 21S-3Q6 B4)	1214
PSS 31S-3MAI	Multiple Analog Input (MAI) Block (Supersedes: PSS 21S-3N9 B4)	0914
PSS 31S-3MAIN	Multiple Analog Input (MAIN) Block (Supersedes: PSS 21S-3D7 B4)	0914
PSS 31S-3MAO	Multiple Analog Input Output (MAO) Block (Supersedes: PSS 21S-3Q13 B4)	0914
PSS 31S-3MATH	Mathematic (MATH) Block (Supersedes: PSS 21S-3L6 B4)	0914
PSS 31S-3MCIN	Multiple Contact Input (MCIN) Block (Supersedes: PSS 21S-3E1 B4)	0914
PSS 31S-3MRIN	Multiple Real Input (MRIN) Block (Supersedes: PSS 21S-3Q4 B4)	0914
PSS 31S-3MSG	Message Generator (MSG) Block (Supersedes: PSS 21S-3L9 B4)	0914
PSS 31S-3MTR	Motor (MTR) Control Block (Supersedes: PSS 21S-3D3 B4)	0914

FOXBORO EVO PROCESS AUTOMATION SYSTEM

Document No.	Title	Date
PSS 31S-3NSTRIN	String Input (STRIN) Block (Supersedes: PSS 21S-3N12 B4)	1214
PSS 31S-3OUTSEL	Output Selection (OUTSEL) Block (Supersedes: PSS 21S-3M1 B4)	0914
PSS 31S-3PAKIN	Packed Input (PAKIN) Block (Supersedes: PSS 21S-3Q7 B4)	0914
PSS 31S-3PAKINR	Redundant Packed Input (PAKINR) Block (Supersedes: PSS 21S-3Q15 B4)	0914
PSS 31S-3PAKOUT	Packed Output (PAKOUT) Block (Supersedes: PSS 21S-3Q8 B4)	1214
PSS 31S-3PATT	Pattern (PATT) Block (Supersedes: PSS 21S-3M9 B4)	0914
PSS 31S-3PATALM	Pattern Alarm (PATALM) Block (Supersedes: PSS 21S-3E7 B4)	0914
PSS 31S-3PID	Proportional-Integral-Derivative (PID) Controller (Supersedes: PSS 21S-3E9 B4)	0914
PSS 31S-3PIDA	Adaptive Feedback and Feedforward Controller (PIDA) (Supersedes: PSS 21S-3M2 B4)	0914
PSS 31S-3PIDE	EXACT Proportional-Integral-Derivative (PIDE) Controller (Supersedes: PSS 21S-3F1 B4)	0914
PSS 31S-3PIDX	Extended Proportional-Integral-Derivative (PIDX) Controller (Supersedes: PSS 21S-3F3 B4)	0914
PSS 31S-3PLCIO	Programmable Logic Controller Input/Output (PLCIO) Block (Supersedes: PSS 21S-3Q10 B4)	0914
PSS 31S-3PLSOUT	Pulse Output (PLSOUT) Block (Supersedes: PSS 21S-3Q9 B4)	1214
PSS 31S-3PTC	Proportional Time Controller (PTC) Block (Supersedes: PSS 21S-3F9 B4)	0914
PSS 31S-3RAMP	Ramp (RAMP) Function Generator Block (Supersedes: PSS 21S-3G1 B4)	0914
PSS 31S-3RATIO	Ratio (RATIO) Block (Supersedes: PSS 21S-3G3 B4)	0914
PSS 31S-3REALM	Real Alarm (REALM) Block (Supersedes: PSS 21S-3G5 B4)	0914
PSS 31S-3RIN	Real Input (RIN) Block (Supersedes: PSS 21S-3N8 B4)	0914

FOXBORO EVO PROCESS AUTOMATION SYSTEM

Document No.	Title	Date
PSS 31S-3RINR	Redundant Real Input (RINR) Block (Supersedes: PSS 21S-3N10 B4)	0914
PSS 31S-3ROUT	Real Output (ROUT) Block (Supersedes: PSS 21S-3N9 B4)	0914
PSS 31S-3ROUTR	Redundant Real Output (ROUTR) Block (Supersedes: PSS 21S-3N14 B4)	0914
PSS 31S-3SIGSEL	Signal Selector (SIGSEL) Block (Supersedes: PSS 21S-3G7 B4)	0914
PSS 31S-3STATE	State (STATE) Block (Supersedes: PSS 21S-3N4 B4)	0914
PSS 31S-3STALM	State Alarm (STALM) Block (Supersedes: PSS 21S-3M3 B4)	0914
PSS 31S-3SWCH	Switch (SWCH) Block (Supersedes: PSS 21S-3H7 B4)	0914
PSS 31S-3VLV	On-Off Valve (VLV) Block (Supersedes: PSS 21S-3E5 B4)	0914

Information Suite Software

PSS 21S-4Y1B3	AIM*AT Alarm and Message Interface Software	0812
PSS 21S-6AIMDL	AIM*DataLink (Supersedes: PSS 21S-6C4 B3)	1114
PSS 21S-6AIMEXP	AIM*Explorer (Supersedes: PSS 21S-7A5 B3)	1114
PSS 21S-6AIMHST	AIM*Historian (Supersedes: PSS 21S-6C1 B3)	1114
PSS 21S-6AIMOPC	AIM*AT Implementation of OPC Server (Supersedes: PSS 21S-6D10 B3)	1114
PSS 21S-6AIMINF	AIM*Inform (Supersedes: PSS 21S-6C9 B3)	1114
PSS 21S-6ISRP	Information Suite Report Package (Supersedes: PSS 21S-6C8 B3)	1114

Advanced Applications

PSS 31S-2ALMSHLV	Alarm Shelving Tool Software (Supersedes: PSS 21S-2B12 B4, PSS 31S-2ALMSHELV)	0718
PSS 31S-2SALMSHL	System Auditor Alarm Shelving Utility	1217

FOXBORO EVO PROCESS AUTOMATION SYSTEM

Document No.	Title	Date
PSS 31S-7B5	OPC Alarm and Event (A&E) Client Software	0115
PSS 31S-7CTS	FoxCTS - Change Tracking Software	0118
PSS 31S-7FXBRDG	FoxBridge Software	0518
PSS 31S-7INI	Information Network Interface (INI) Software for Solaris Systems and Windows Systems	0715
PSS 31S-7PAGE	FoxPage and Event Driven Scripts Software (Supersedes: PSS 21S-7A9 B3)	0915
PSS 31S-7SW_TOOL	Foxboro Evo and I/A Series Tools Suite: cpShell, FBMTrack, MMessage Logger, OAJRelay/SMONRelay, SSCSupport, and Tag Search (Supersedes: PSS 31S-7Sw-Tool, PSS 31S-7B2 B3)	1015

FOXBORO EVO SOFTWARE

Control Software

PSS 31S-10DEVNET	Field Device Editor for DeviceNet (Supersedes: PSS 31S-10B14 B3, PSS 21S-10B14 B3)	0914
PSS 31S-10EDITOR	Control Editors (Supersedes: PSS 31S-10B14 B3, PSS 21S-10B14 B3)	0318
PSS 31S-10FDMFF	Field Device Manager for FOUNDATION fieldbus (Supersedes: PSS 31S-10B6 B3, PSS 21S-10B6 B3)	0318
PSS 31S-10FDMHART	Field Device Manager for HART Devices Control and I/O (Supersedes: PSS 31S-10B16 B3, PSS 21S-10B16 B3, PSS 31S-10FDMHART)	0318
PSS 31S-10FDMPB	Field Device Manager for PROFIBUS-DP Devices (Supersedes: PSS 31S-10B4 B3, PSS 21S-10B12 B3)	0318
PSS 31S-10FF	Control Software with FOUNDATION fieldbus (Supersedes: PSS 31S-10B10B3, PSS 21S-10B10B3)	0914
PSS 31S-10G4	Foxboro Evo Substation Automation Configuration (SAC)	0914
PSS 31S-10HISTCL	Wonderware Historian Client (Supersedes: PSS 31S-10B12 B3)	1214
PSS 31S-10HMI	Control HMI Application (Supersedes: PSS 31S-10B2 B3)	1214
PSS 31S-10LBEDIT	Logic Block Editor and Live Data Display	0914

FOXBORO EVO PROCESS AUTOMATION SYSTEM

Document No.	Title	Date
PSS 31S-4TRIAUD	EcoStruxure System Advisor - Process Safety	1217
PSS 31S-10MRC	Maintenance Response Center	0616
PSS 31S-10SCRIPT	Scripting with Direct Access (Supersedes: PSS 31S-10B9 B3)	1214
PSS 31S-10SYSMGR	System Manager (Control Core Services and Control Software)	0318
PSS 31S-10WWHIST	Wonderware Historian (Supersedes: PSS 31S-10B11B3, PSS 21S-10B11B3)	0914
PSS 31S-10WWIS	Wonderware Information Server (Supersedes: PSS 31S-10B2 B3)	1214

