


## I/A Series<sup>®</sup> Software

### Alarm Priority (ALMPRI) Change Block



*The Alarm Priority (ALMPRI) change block dynamically reassigns the priority of an alarm point based on specific plant conditions.*

#### OVERVIEW

The ALMPRI supports up to 5 Boolean-type inputs that represent the five priority levels of alarming. The block output is an integer-type parameter that represents the lowest numbered (highest priority) active input. When the output is connected to a priority input of another block, that block's alarm priority is then established by the output of the ALMPRI block.

#### STANDARD FEATURES

- Auto/Manual control of output
- 5 Boolean inputs

**The Foxboro Company**

33 Commercial Street

Foxboro, Massachusetts 02035-2099

United States of America

<http://www.foxboro.com>

Inside U.S.: 1-508-543-8750 or 1-888-FOXBORO (1-888-369-2676)

Outside U.S.: Contact your local Foxboro Representative.

Foxboro and I/A Series are registered trademarks of The Foxboro Company.

Copyright 1987 by The Foxboro Company

All rights reserved

MB 021

Printed in U.S.A.

0487

**An Invensys company**